

# **Quality Sales Co., Inc.**

## **Customer Information**

### **Marble Tub Wraps**

- The tub should be leveled and hooked up by the plumber before the marble installation date. If you have a whirlpool tub the electrical should also be hooked up before we come.
- Any inspections should be done before the marble installation date.
- If we are installing a skirt (the front of the tub) the customer should have the frame work completed and recessed to 1”.
- The walls must be sheet rocked. We ask that the sheet rock be raw,(no painting, floating, texture, or sizing) below or behind the height and width of the marble for proper adhesion. Green sheet rock is not acceptable, as it contains a sealer that will not allow our glues to properly adhere to it.
- The location of the shampoo dish or accessory center is to be written on the sheet rock wall by the customer, otherwise the installer will locate it in a standard location. (The customer needs to consider the location of studs, vent pipes, plumbing pipes, electrical wires, etc.)
- If the bathroom floor is to have tile, the tile needs to be installed first, before the skirt is installed.
- Once the silicone caulking has been applied, it needs to dry for 24 hours, without water or anything else touching it to properly cure.
- To clean cultured marble please refer to Quality Sales Co. Care Instructions.