

# Quality Sales Co., Inc.

## Customer Information

### Showers

- On all custom shower floors (any size up to 72" x 120") the drain does not have to be centered, but will drain best when located as close to the center as possible. We prefer the shower floor to be recessed 5 ½" (the width of a 2x6) from the slab level. This will require a 2" PVC pipe to be stubbed up approximately 6" high and our installers will cut it to the correct height.
- If the shower floor is not recessed a 2" PVC FHA drain and vinyl shower pan must be installed. This is normally supplied and installed by your plumber. However, we can provide and install the shower pan upon special request, but there will be an additional charge and you must have the 2" PVC pipe installed first.
- The walls and ceiling must be sheet rocked. We ask that the sheetrock be raw, (no painting, floating, texture or sizing) for proper adhesion. Green sheetrock is not acceptable, as it contains a sealer that will not allow our glues to properly adhere to it.
- A threshold must be built out of treated wood for a shower that is not recessed. It should either be made from 2- 2 x 6's nailed together, standing up sideways or 3- 2 x 4's stacked up to achieve the proper height.
- The plumbing fixtures should be stubbed out to the proper measurements. The thickness of the marble is normally 3/8", but after we add adhesive the overall thickness is ½".
- The location of the shampoo dish or accessory center is to be written on the sheetrock wall by the customer, otherwise the installer will locate it in a standard location. (The customer needs to consider the location of studs, vent pipes, plumbing pipes electrical wires, etc.)
- Once the silicone caulking has been applied, it needs to dry for 24 hours, without water or anything touching it, to properly cure.
- To clean cultured marble please refer to Quality Sales Co. Care Instructions.